eFollower[®]

Stylus Pen H108

User's Guide



Features

This guide describes how to use the eFollower stylus pen. Be sure that you read this guide and understand its contents before using it.

It is a stylus pen for touch screens with Pg up, Pg down, black screen, slider/exit, hyperlink and other features. There are even customization keys and the following functions as well:

1. By using the following three digital scene modes, pen operation is more convenient and powerful.

Spotlight Mode

Magnifier Mode



Digi-Laser Mode



2. We can set up an alarm timer in the meeting.

5. The receiver anti-lost function can help us not to forget unplugging the USB receiver after meeting.

6. The Full-time-markup function support users to draw line on screen at any time.

Operation Steps

Step 1: Plug the Receiver into USB Port

Plug the receiver into the USB port of the computer.

Step 2: The Receiver Establish Connection with The Computer

If the receiver is plugged into a computer with Windows 10 or below for the first time, it needs to establish communication with the computer for several minutes, depending on the speed of the computer.

Step 3: Run the APP (compute aided software)

It needs to run the computer aided software before use, without running APP, it cannot support the advanced functions such as spotlight, magnifier, digital spot, alarm timer and so on.

Most Windows computers without special restrictions will automatically download and run the computer aided software after the USB receiver is plugged in the USB port of computer (wait a few minutes for the first time).

The computers with special restrictions or the illegally installed Windows are not allowed to download and run the APP automatically. However, we can manually download the software from <u>https://www.yxssm.com</u> and run it by ourselves (click "<u>Run the Computer Aided Software</u>" for details).

Step 4: Wake up the Pen

It has no switch, press any key to wake up the pen.

- A) The light will indicate the residual electricity. The greener means the more residual electricity, the redder means the less residual electricity, and the red-light flashing means the power is out.
- B) The green light means it have taken a correct connection with receiver and the icon of APP change



If it doesn't display anything means the batteries died.

Keys Description

1. Single Key



The blue part above is optional. See "Key Settings" for details.

2. Combination Keys

A) Press and hold key (4) for one second and then press the key (2) simultaneously to reduce the aperture of current scene.

B) Press and hold key (4) for one second and then press the key (3) simultaneously to enlarge the aperture of current scene.

C) Press and hold key (2) + key (3) until the green light is on means it is in the calibration status. (it is useful when mouse movement and gestures are inconsistent) See "<u>Circles Drifts in Scene Mode</u>" for details.

D) Press and hold the key (1) + key (3) until the red light is on after flashing for five times means the pen is in wireless re-pair mode. See "Re-pair with Receiver" for details.

Re-pair with Receiver

A) Press and hold the key (1) + key (3) until the red light is on after flashing for five times means the pen is in

wireless re-pair mode.

B) Plug in USB receiver, press and hold the key 4 and move it close to the receiver (in 20cm). The re-pair is successful if the computer has any reaction.

Indicator

1. Residual Electricity Displayed after Wake-up from Sleep

The light will be on for 2 seconds after turning it on. The greener means the more residual electricity, the redder means the less residual electricity. The red-light blinks, which means the battery is dead, and we need to charge it by the charging cable as same as Android phones.

2. Charge light indication

The red light is always on when charging, and the green light is on when full.

Special Cases

1. Nothing Happened after Starting

Please make sure:

A) The receiver is plugged into the USB port of the computer.

B) The battery is not out of power.

2.Pen Is Not Working Properly

A) Make sure the battery is not out of power, the switch is turned on, and the receiver is correctly plugged into the USB port of the computer.

B) Make sure that the APP is running. even if the software is not running, the page up, page down function and the laser transmitter can still be used.

C) Try to re-pair it with receiver.

3.Circle Drifts in Scene Mode

The gyroscope sensor needs to be re-calibrated when the circle movement appears to be drifting. The operation steps are as following:

are as following.

A) Press and hold key (2) + key(3) until the green light is on means it is in the calibration status.

B) Put the pen on the desk statically until the red-light goes out. It shows the calibration is successful.

Note: During gyroscope sensor re-calibration, the pen cannot be placed on a shaking or slightly vibrating table.

4.No Spotlight/Magnifier/Digital-spot

Please confirm whether the APP is running. Double-click the. EXE file to run the Windows version (if it cannot run after plugging the receiver).

In MacOS X system, we require double-click the ". dmg" file to install it before running. Some necessary

configuration must be set at the first run. See "First Run in MacOS X" for details.

5.Incorrect Magnifier

A) In MacOS X system

This is because some permissions in the "System Preferences" section of MacOS X are not turned on.

I) Enter "System Preferences"-->"security and privacy" --> "Privacy"--> "Accessibility " and select the APP to allow this APP.

II) Enter "System Preferences"-->"security and privacy" -- > "Privacy"--> "Screen Recording" and select the APP to allow this APP in MacOS X 10.15 or above.

See "First Run in MacOS X" for details.

B) In Windows system please contact customer service.

6.Reset the Pen

In extreme cases where the pen is not work properly and can not be restored to normal. Press and hold key 1 + key 3 + key 4 at the same time, then release them to reset the pen.

APP Settings

2. Multilingual Support

The APP displays different language according to the base language of the operating system automatically. Chinese and English operating systems are supported currently.

2. General Settings



A) The white question mark icon in the title bar is the help icon. Click to open the help file. The help file is saved on the network server. Therefore, the computer should be able to connect to the Internet normally.

B) Receiver anti-lost: After the turn off the presenter or wireless disconnection for 20 seconds, and the receiver

has not pulled out the USB port of the computer, the computer will play a voice to remind the user not to forget to pull out the receiver. Of course, only when the computer speaker is on.

C) Alarm timer: Input the alarm timer (maximum: 199 minutes) by keyboard.

" Display on screen " button: The countdown timer is displayed on the screen, and the music reminder will be played when the time is up (the computer speaker should be turned on).

3.Keys Settings



3.1 " D-Click " Combo box

A) Scenes switch: Double click this key is to switch among **Spotlight, Magnifier and Digital spot**. (no mouse left double click function)

B) Mouse d-click: Selecting this item means that the "Spotlight" and "Magnifier" functions are forbidden.

Press and hold this key will enter "Digital spot" function. double click this key is equivalent to the left mouse button.

C) Pgup / Pgdn key can be selected from four options: "Pgup / Pgdn, up/down, left/right, previous track /next track".

3.2 Selection of Customized Keys

Despite some preset key value items of popup menu, the most important item is "Customized key" by

which we can define the key value as any keys on the keyboard. If you select this item, the following dialog box will pop up. At this time, just press the specific keys on the computer as we will.

Please input the combination keys	
(Customized Key)	
Cancel	

Note: The self-defined key value is saved into presenter after setting. So, the key value remains unchanged until they are changed in APP.

4. APP Menu of Windows Version

Right-click on the icon in the tray, the menu will pop up. Online Store
Technical Support
Shortcut Processes
Auto startup
Open Setting Window
Quit Application
Delete this Program

Open Setting Window: Open the settings window. This function is the same as left clicking the icon.

Auto startup: This program will run automatically when the computer is turned on.

Start on device inserted: After the receiver is inserted, the software runs automatically.

Delete this program: Quit and delete itself from computer. (If we plug the receiver again, the APP

will be downloaded and run again, unless "Start on device inserted" is closed).

5.Status of APP Icon

The icon represents a stable connection. Click it to enter the setting window.

The icon represents an abnormal connection means presenter is not turned on or the receiver is not inserted into USB port of computer.

Run the Computer Aided Software (APP)

3. The APP Location

We can also download the APP from: https://www.yxssm.com/

2. Start the APP of Windows Version

2.1 Double-click to Run It

The APP of Windows need not be pre-installed before use. Just mouse double-click the "eFollowerPresenterG2.exe" to run it. The APP will set a shortcut on desktop. it will run automatically at the next startup of computer.

If it doesn't work on early version of Windows7, please download and install.<u>Net framework 4.0</u> (click the blue word to enter the Microsoft download URL)

2.2 APP Setting and Quitting

Click the icon ,which lies in the tray of lower right corner of desktop, by the right mouse button to open the popup menu. We can choose to open the settings window or quit the APP. Click the icon by the left mouse button to open the settings window directly.

3. Start the APP of MacOS X Version

3.3.1 APP Installation

- A) For the first time, download and double-click the file "efollowerPresenterG2_Mac.dmg"
- B) Drag the icon "efollowerPresenterG2" into Application folder to install the APP.

	● ● ●	
	Presenter Installa	tion
	易相随翻页笔 App	lications
	Drag into the Application folder to inst	all APP
Check: Open "Launch	npad", There is an application 🧭	means installation is successful.

3.3.2 First Run in MacOS X

A) If Popup the Warning "File is corrupted"

We had better type "sudo SPCTL --master-disable" and then type Enter key in the

Terminal window after downloading and then install it. This is due to MacOS X's security


mechanism, which defines any software downloaded outside the Apple Store as insecure.


However, if we copy the downloaded file to the U-disk and then install it from the U-disk,

this prompt will probably not appear.

B) If Popup the Warning "Open an app from an unidentified developer"

MacOS X has this prompt for any program that is not downloaded from the Apple Store. Just do the following steps for the first time.






 Safari downloaded this file today at 12:53 PM from presenter2.oss-cn-shenzhen.aliyuncs.com.

 Open
 Cancel

B) Pop-up Warning "enable accessibility access"

After clicking the APP icon in the "Launchpad", the following pop-up warning appears.



This is the permission required for the APP. it won't appear again after setting as follows.

I) Click "Later" that runs the software for this time. However, this warning will appear for every run.

II) Click "OK" and the following window appears.

We can also set it in "System Preference"-->"Security and Privacy"-->"Privacy"--> "Accessibility " at any time.

••• < > ==	Security & Privacy	Q Search
General	FileVault Firewall Privat	су
Location Services	Allow the apps below to cor	ntrol your computer.
Contacts		
Calendars	o 🕖 eFollowerPreser	
Reminders	erollowerPreser	hter
🛞 Photos	Calastia	
Camera	Select to	open
фф Microphone	+ -	
speech Recognition		
Accessibility		
	uncloc	k
Click the lock to prevent further c	hanges.	Advanced ?

- * Click the bottom part to unlock it(need to enter the account password).
- * Select the check box before APP icon.
- * Click the bottom part to lock the setting again.
- * Re-run the APP from launchpad.

If the APP runs on MacOS X10.15 or later, we need to turn on the "Screen Recording" permission,

otherwise the magnifier scene will not work correctly.

"System Preferences"-->"security and privacy" -- > "Privacy"--> "Screen Recording"



3.3.3 APP Setting and Quitting

Click the icon, which lies in the corner of upper right corner of desktop, to open the settings windows or to quit the APP.



Shenzhen Haojiehua Technology Co.,Ltd Room B1-619, Huayuan science and technology park, Bao Yuan Road, Baoan District, Shenzhen, Guangdong, China Technical Support: <u>support@haojiehua.com</u>